



Point load is transferred between studs by rim closure material acting as header. If rim closure material is non-structural support will be required under point loads. Use solid blocking between joists